
黑鲨凤鸣头戴式游戏耳机


Black Shark JoyBuds Max

使用产品前请仔细阅读本说明书，并妥善保管。

Read this manual carefully before use, and retain it for future reference.

产品介绍


音量键
开关机键
LED指示灯
Type-C充电口
3.5mm AUV音频口
通话麦克风
ANC按键


可伸缩头梁
可折叠结构
前馈麦克风

使用说明

规格信息

耳机名称：黑鲨凤鸣头戴式蓝牙耳机
耳机型号：BE30
配对名称：Black Shark JoyBuds Max
蓝牙版本：Bluetooth V5.4
音频解码：AAC,SBC
喇叭：40mm镀钛复合振膜
频率响应：20HZ-20KHZ
充电接口：Type-C
电池容量：500mAh
充电时间：1.5-2H
待机时间：110H（开机状态）---ANC OFF;55H---ANC ON
音乐续航时长：约50H关闭ANC（开启ANC约30H）
包装清单：耳机，音频线，充电线，说明书，二维码卡片

操作说明

功能	操作	鲨鲨酱提示音
开机	关机状态下，长按开关机键3s开机	支持
关机	开机状态下，长按开关机键3s关机	支持
配对管理	开机后白色指示灯闪烁，搜索蓝牙广播名Black Shark JoyBuds MAX进行配对；无连接状态5分钟后自动关机；开机状态下长按开关机键10s进行重置，红灯闪烁2下，进行重新配对	支持
来电接听	来电状态下，按一下开关机键可接听	支持
挂电话	通话状态下，按一下开关机键可挂断通话	/
来电拒接	来电状态下，长按开关机键	/
播放/暂停	连接状态下，按一下开关机键在“播放/暂停”间切换	/
上一曲/下一曲	上一曲：长按音量“-”上一曲 下一曲：长按音量“+”下一曲	/
音量调节	加：按音量加减键“+” 减：按音量加减键“-”	/
模式切换	双击开关机键切换游戏模式、音乐模式	支持
降噪ANC	单击ANC按键切换主动降噪、正常模式、通透模式（顺切）	支持
Siri功能	三击开关机键	/

注意事项

1.请在常温的环境中存放使用本产品。
2.请勿将本产品暴露在雨中或是潮湿的环境中。
3.请勿丢掷，避免因跌落造成产品损坏。
4.请勿拆解，修理和改造本产品。
5.请勿使用化学溶剂擦拭本产品。
6.请勿随意丢弃，或置于高温（温度高于60度）与火中，以免引起危险。

体验更多玩法

扫描二维码 下载安装APP。




法律声明


版权所有©2024 深圳铭源电玩科技股份有限公司。保留一切权利。本说明书仅供参考，示意图与实物可能存在细微差别，请以实物为准。如出现本说明书与官网描述不一致的情况，请以官网描述为准。黑鲨可能随时更新本说明书，恕不另行通知。更新内容将会合入本说明书的新版本中。

服务政策

本产品依法享有国家规定的三包服务，您可以访问黑鲨外设官网的服务页面，或查阅在线说明书了解具体细则。
黑鲨外设官网：http://esports.blackshark.com/

INTRODUCTION





SPEC

Name: Black Shark JoyBuds MAX

Model: BE30

Pairing Name: Black Shark JoyBuds Max

Bluetooth: Bluetooth V5.4

Decoding: AAC, SBC

Speaker: 40mm Titanium Pated Composite Diaphragm

Frequency: 20HZ-20KHZ

Charging Port: Type-C

Battery: 500mAh

Charging Time: 1.5-2 Hours

Standby Time: 110 Hours（When On)---ANC OFF; 55 Hours---ANC ON

Battery Life (Playing Music): Approx. 50 hours with ANC off (approx. 30H with ANC on)

In-the-box: Headphone, Audio Cable, Charging Cable, Manual, QR Code Card

HOW TO USE

Function	Operation	Voice Prompt
Turn On	long press the on/off button for 3 seconds	Support
Turn Off	long press the on/off button for 3 seconds	Support
Pairing	1. Power on 2. Indicator flash in white 3. Search for BlackShark JoyBuds MAX in the Bluetooth list and pair it. 4. If there is no connection, it will turn off automatically after 5 minutes. 5. Press and hold the on/off button for 10 seconds to reset, the indicator flash in red twice to re-pair.	Support
Answer the phone	Press the on/off button to answer	Support
Hang up the phone	Press the on/off button to hang up	/
Incoming call rejection	Long press the on/off button to reject calls	/
Play / Pause	Press the on/off button to play or pause	/
Previous / Next	Previous song: Long press volume - button Next song: Long press volume + button	/
Adjust the volume	Volume up: press volume + button Volume down: press volume - button	/
Change Mode	Double-tap the on/off button to switch between game mode and music mode	Support
ANC	Click the ANC button to switch between Active Noise Reduction, Normal Mode and Transparency Mode	Support
Siri	Tap the on/off button 3 times	/

CAUTIONS

1. Store and use this product in a room temperature environment.
2. Do not expose the product to rain or a humid environment.
3. Do not throw the product to avoid damage caused by dropping.
4. Do not disassemble, repair or modify the product.
5. Do not use chemical solvents to clean the product.
6. Do not dispose of the product or expose it to high temperatures (above 60 degrees Celsius) or fire, as this may cause danger.

BLACK SHARK ARSENAL

Scan and download the app



BLACK SHARK

安全信息、服务政策等更多详情，以及更多语言版本，
请扫码查阅在线说明书。

For more information about safety, regulations, multilingual information, etc,
please scan the QR code to view the online user manual.